

Installation Guidance

AutoLux Looms – Nissan Navara NP300 High Beam Wiring Kit

Red – To (+) battery terminal

Yellow – To (+) of additional lighting



Read this guidance prior to installation

Read the guidance fully prior to installation of our wiring kit.

Installation

1. **DISCONNECT BATTERY** – If this step is not followed you could cause damage to your vehicle and your new AutoLux Loom.
2. Mount the Relay using the provided fixture.
 - a. NOTE: Check the length of Red Wire will reach the Positive Battery Terminal
3. Connect the Yellow Wire to your positive wire (+) on your Lightbar.
4. Earth/Ground the Black wire (-) of your Lightbar to the body of your vehicle.
 - a. NOTE: This must be a metal location.
5. Unplug your Headlight Plug, in its place connect AutoLux's Piggyback Loom and re connect your Headlight Plug back into AutoLux's Piggyback Loom.
6. Connect the Red Wire to the Battery Positive (+).

Only to be used with 12V DC

MAX 300 watts

Included in the kit:

Wiring Kit, S/S Bolt w/washer

Guarantee will be VOID if this installation guidance is not followed